

SKF Microlog Frequency Response Function (FRF) Module

Creating non-animated mode shapes from Frequency Response Function module data imported into the Analysis and Report Module

Summary

This document describes the procedure for creating non-animated mode shapes from Frequency Response Function (FRF) data imported into the Analysis and Reporting Module (ARM). This is a technique known as “poor man’s modal”.

Procedure

Step 1: Start by importing the FRF data from the SKF Microlog using the Mobile Device Viewer.

Note: Make sure you have FRF files selected as the source (internal memory and SD card)




Figure 1. “FRF files” selected as the source.

Step 2: Highlight all the files for import and select **Next**.



Figure 2. Mobile Device Viewer window.

Step 3: All selected files will be transferred to the ARM's main window.




Figure 3. SKF Analysis and Reporting Module screen.

Step 4: Select trace 1 “X” and drag the FRF Imag spectrum onto a clear space of the data file window to create a new data file.




Figure 4. SKF Analysis and Reporting Module screen – creating a new data file.

Step 5: Copy all other FRF Imag spectra from the individual files into the FRF Imag from 1 “X” to create a group of spectra.




Figure 5. SKF Analysis and Reporting Module screen – creating a group of spectra.

Step 6: Select the second level of the group to select and view all traces.




Figure 6. SKF Analysis and Reporting Module screen – viewing all traces.

Step 7: Using either the waterfall icon or selecting **Waterfall** from the **Graph, Change plot type**, change the view to a waterfall.




Figure 7. SKF Analysis and Reporting Module screen – viewing a waterfall.

Step 8: From the **Graph, Y axis, Scale** dropdown menu, select **Imaginary** to revert the plot to imaginary data.




Figure 8. SKF Analysis and Reporting Module screen – viewing imaginary data.

Step 9: Move the cursor over a frequency of interest, right-click it and select **Waterfall Slice**.

Step 10: A new data window will display the mode shape of the selected frequency.

Note: This procedure will not show any torsional mode shapes; these can only be shown in MEScope.




Figure 9. SKF Analysis and Reporting Module screen – viewing a waterfall slice.

Please contact:

SKF USA Inc.

Condition Monitoring Center – San Diego

5271 Viewridge Court · San Diego, California 92123 USA

Tel: +1 858-496-3400 · Fax: +1 858 496-3531

Web: www.skf.com/cm

© SKF and MICROLOG are registered trademarks of the SKF Group.

All other trademarks are the property of their respective owners.

© SKF Group 2011

The contents of this publication are the copyright of the publisher and may not be reproduced (even extracts) unless prior written permission is granted. Every care has been taken to ensure the accuracy of the information contained in this publication but no liability can be accepted for any loss or damage whether direct, indirect or consequential arising out of the use of the information contained herein.

PUB CM3143 EN · September 2011

