`

Inquire – Knowledge Base Article

Product Group: Software
Product: CMSW7400 @ptitude Analyst
Version: N/A

Abstract
This article provides information on a keyboard sequence to initiate @ptitude Analyst Global Open and Close.

Overview
For all versions of Machine Analyst and @ptitude Analyst (tested on v6.2), the asterisk (*) key on a numeric keypad will expand all branches of the selected hierarchy level.

If many branches are below the selected hierarchy level, a noticeable lag may occur before the sub-levels appear on the screen. The only obvious indication of action is a slight up-and-down movement of the scroll bar in the hierarchy window. Once the expansion is complete, all of the expanded levels will appear.

The combination of the **[Ctrl]** key and the asterisk (*****) key on the numeric keypad will close all the branches of the selected hierarchy level.

For further assistance, please contact the Technical Support Group by phone at 1-800-523-7514 option 8, or by email at tsg-americas@skf.com.

SKF Reliability Systems
5271 Viewridge Court * San Diego, California, 92123 USA
Telephone 1-800-523-7514 Web: www.skf.com

SBPCDZ Rev A
Page 1 of 1