

## Inquire – Knowledge Base Article

**Product Group:** Software MARLIN **Product:** CMSW7400 @ptitude Analyst **Version:** 5.0.5.2

## Abstract

This article describes how to both manually and automatically populate Derived POINTs (even though the Assigned Points do have data), when the Derived POINTs are not being populated.

## Overview

There are two types of Derived POINTs:

- Calculated Derived POINTs
- MARLIN Derived POINTs

With Calculated Derived POINTs, the only way the data for the Derived POINTs will automatically calculate (v6.0 and earlier of @ptitude Analyst) is when the Monitor Service is running. Without the Monitor Service running, a calculation may be done manually by selecting **Edit**  $\rightarrow$  **Calculate Derived POINTs** on the menu. This method is also known as a *force calculation*.

With MARLIN Derived POINTs, the data for the Derived POINTs is calculated immediately by the MARLIN, once the data for the mandatory Assigned Points has been collected to satisfy the Derived POINTs specifications.

Sometimes, the Calculated Derived POINTs must be deleted and the MARLIN Derived POINTs must be created, in cases where the user will be using MARLIN to collect the data.

\_\_\_\_

For further assistance, please contact the Technical Support Group by phone at 1-800-523-7514 option 8, or by email at <u>tsg-americas@skf.com</u>.



**SKF Reliability Systems** 5271 Viewridge Court \* San Diego, California, 92123 USA Telephone 1-800-523-7514 Web: www.skf.com