

Knowledge Base Article

Product Group: Microlog Analyzer

Product: CMXA70; CMXA75; CMXA80

Version: N/A

Abstract

The ActiveSync partnership is provided for synchronizing Microsoft Exchange contacts, appointments, tasks, etc. between the portable device and the host computer. Since Microlog Analyzers do not use Microsoft Exchange, it should not cause a problem if a partnership is created. This article provides instructions for removing the partnership.

Overview

An ActiveSync partnership can be removed by performing the following steps:

1. Connect the Microlog to the computer and open ActiveSync.
2. Go to **File > Mobile Device >** and select the partnership to delete.
3. Select **File > Delete Partnership**.

The partnership is now deleted.

For further assistance, please contact the Technical Support Group by phone at 1-800-523-7514 option 8, or by email at TSG-Americas@skf.com.