

Knowledge Base Article

Product Group: Software

Product: CMSW7400 - @ptitude Analyst

Version: N/A

Abstract

The SKF @ptitude Analyst Configuration Tool has the ability to make changes to the application configuration. Some of these changes are made to files on the client PC, while other changes actually require a connection to the database. In order for the SKF @ptitude Analyst Configuration Tool to connect to the database, the SQL Native Client (SQLCMD.exe) must be installed. This document describes how to install Microsoft SQL Server Management Studio and SQLCMD.exe from the MS SQL Server installation file supplied on the @ptitude Analyst DVD.

Overview

Follow the steps below to install the SQLCMD.exe installation file:

1. Insert the @ptitude Analyst installation DVD into the PC where the SQL Native Client needs to be installed.
2. Explore the contents of the disk. Open **DB_INST > SQL**, and then double-click the file, **SQLEXPRWT_x86_ENU**. [Figure 1]




Figure 1. Exploring @ptitude installation DVD

- The installation files will begin extracting. [Figure 2]



Figure 2. Extracting files

- When the file extraction is complete, setup will begin. [Figure 3]



Figure 3. Setup has begun

- Click on **New Installation or add features to an existing installation.** [Figure 4]




Figure 4. Installation Center

6. Setup will continue. [Figure 5]



Figure 5. Continuing setup

7. Check the box, "I accept the license terms" [Figure 6], then click **Next >**.




Figure 6. Read and accept the license terms

- The **Setup Support Files** will be displayed. [Figure 7]




Figure 7. Setup Support Files window

- Under Shared Features, check the box next to **Management Tools – Basic** and also **SQL Client Connectivity SDK** [Figure 8]. If the default installation location needs to be changed, make the change by clicking the browse button [...] located to the right of the path. Click **Next >** to continue.




Figure 8. Feature Selection window

- Do not select anything on the Error Reporting page. [Figure 9]
Click **Next >**.




Figure 9. Error Reporting window

- When the installation is done, the Complete page [Figure 10] will be displayed. Click **Close** to finalize the install.




Figure 10. The installation is complete

- Click the **[X]** in the upper right corner [Figure 11] to close the Microsoft SQL Server Installation Center window.



Figure 11. Exit the application

The SQL Native Client is now installed and the SKF @ptitude Analyst Configuration Tool now has the ability to make a connection to the database.

For further assistance, please contact the Technical Support Group by phone at 1-800-523-7514 option 8, or by email at TSG-Americas@skf.com.