

Knowledge Base Article

Product Group: Software

Product: CMSW7308 - @ptitude Analyst Trend Oil

Version: N/A

Abstract

This article provides instructions on importing a Trend Oil Sample template in SKF @ptitude Analyst.

Overview

Follow the instructions below to import an Oil Sample template:

1. From the main menu, select **File → Import → Oil Analysis...** [Figure 1]




Figure 1. Import option

2. Highlight the **Lab** where the oil samples are coming from.
3. Click [Browse] to select the oil sample template to import. [Figure 2]




Figure 2. Select template to import

4. Check the box next to **'Save import feed back to "OilImport.log"'** and press [Next] to proceed with the import.

5. Press [Next] again to continue. [Figure 3]




Figure 3. Import confirmation

6. A blue progress bar will display while data is being imported. Data will only be imported for POINTs that have an oil tag. [Figure 4]




Figure 4. Importing data

The status message, “Measurements were made but no points were found...” means the template contains data for an oil tag that was not found in the database. This message will not be covered in the scope of this article.

7. Press [Finish].

8. POINTs with oil tags that contain data will populate/update. [Figure 5]




Figure 5. TEST OIL POINTS

9. Oil samples may now be analyzed.

For further assistance, please contact the Technical Support Group by phone at 1-800-523-7514 option 8, or by email at tsg-americas@skf.com.

